Installation of USB Device Driver

Windows XP: USB device driver is installed automatically when you run CICON after CICON installation.

Windows 7: Install USB device driver as following steps :

1. Turn PLC power on and connect PLC to PC with USB cable. Select [Control Panel] → [Devices and Printers]

🖉 🕫 🕨 Control Panel 🕨 All Co	ntrol Panel Items 🕨	- €	Search Control Panel	۶
Adjust your computer's settings		View by: Small icons 🔻		
🏲 Action Center	😨 Administrative Tools	📑 Aut	toPlay	
🐌 Backup and Restore	Biometric Devices	Col	or Management	
Credential Manager	👚 Date and Time	🕜 Def	ault Programs	_
📑 Desktop Gadgets	🚔 Device Manager	🖶 Dev	vices and Printers	
🖳 Display	Ease of Access Center	🖌 Flas	sh Player	
🔓 Folder Options	🛺 Fonts	🔒 Get	ting Started	
🍓 HomeGroup	No. HP Quick Launch Buttons	🔒 Ind	exing Options	
🌠 Intel(R) GMA Driver for Mobile	🔁 Internet Options	📖 Key	board	
Location and Other Sensors	Mail	J Mo	use	
👯 Network and Sharing Center	📟 Notification Area Icons	🛃 Par	ental Controls	
Performance Information and Tools	Personalization	Pho	one and Modem	
Power Options	🛐 Programs and Features	P Rec	overy	
🔗 Region and Language	🐻 RemoteApp and Desktop Connections	Sou	und	
Speech Recognition	🔞 Sync Center	🕎 Sys	tem	
L Taskbar and Start Menu	Troubleshooting	🍇 Use	er Accounts	
📑 Windows CardSpace	👑 Windows Defender	🔗 Wir	ndows Firewall	

2. There is CIMON PLC in [Unspecified].

Click the right button of the mouse with cursor on the [CIMON PLC] and select [Properties]

Search Devices and Printers • Search Devices and Printers	ters	<u>×</u> ۵
Add a device Add a printer Troubleshoot		• 📀
		*
Fingerprint HP Integrated MARKETING-PC MemoRive PRO USB OPTICAL Sensor Module MOUSE		
Printers and Faxes (3)		
Fax Microsoft XPS Document Writer Send To OneNote 2010		ш
		-
CIMON PLC Model: CIMON PLC Category: Unknown Status: Needs troubleshooting		
Co Co React All Control Panel Items > Devices and Printers + + + Search Devices and Print	ers	٩
Add a device Add a printer Troubleshoot		. ()
		-
Fingerprint Sensor Module MARKETING-PC MemoRive PRO USB OPTICAL MOUSE		-
Fingerprint Sensor Printers and Faxes (3)		
Fingerprint Sensor HP Integrated Module ARKETING-PC MemoRive PRO MemoRive PRO USB OPTICAL MOUSE USB OPTICAL MOUSE		
Fingerprint Sensor HP Integrated Module • Printers and Faxes (3) • Printers and Faxes (3) • Create shortrut		E
Fingerprint Sensor HP Integrated MarKETING-PC Printers and Faxes (3)		A (III)

3. Select [Hardware] tap and click [Properties]

	ION PLC	
Device Fun	ctions:	
Name		Туре
CIMON PLC		Other devices
Device Fun Manufacture Location:	ction Summary er: Unknown Port_#0002.Hub_#000	6

4. Click [Change settings]

General	Driver	Details			
1	CIMON PLC				
	Device	e type:	Other devices		
	Manufacturer:		Unknown Port_#0002.Hub_#0006		
Location:		on:			
To fir	nd a drive	er for this d	evice, click Update	e Driver.	
4			ſ		*
			l	Update Dri	ver
	Thange e	ettings			
		Cuinda			
	shange s				

5. Select [Driver] tap and click [Update Driver]

General	Driver	Details		
1		I PLC		
	Driver Provider: Driver Date:		Unknown Not available	
	Driver	Version:	Not available	
	Digital	Signer:	Not digitally signed	
Di	iver Detai date Drive	ır	To view details about the driver files. To update the driver software for this device.	
<u>R</u> ol	l Back Dri	ver	If the device fails after updating the driver, roll back to the previously installed driver.	
	Disable		Disables the selected device.	
			To uninstall the driver (Advanced).	

6. Select [Browse my computer for driver software] at [Update Driver Software – CIMON PLC]

Update Driver Software - CIMON PLC	X
How do you want to search for driver software?	
Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software for your device, unless you've disabled this feature in your device installation settings.	
Browse my computer for driver software Locate and install driver software manually.	
	Cancel

- 7. Select [Usb_Driver] folder where CICON is installed and click [Next]
- * In case of Windows 7 64Bit, Select [Usb_Driver] → [OS_64Bit] folder

G I Update Driver Software - CIMON PLC	x
Browse for driver software on your computer	
Search for driver software in this location:	1
✓ Include subfolders	J.,
Let me pick from a list of device drivers on my computer This list will show installed driver software compatible with the device, and all driver software in the same category as the device.	
Next	Cancel

8. Select [Install this driver software anyway] at [Windows Security]

8	Windows can't verify the publisher of this driver software
	Don't install this driver software You should check your manufacturer's website for updated driver software for your device.
	Install this driver software anyway Only install driver software obtained from your manufacturer's website or disc. Unsigned software from other sources may harm your computer or steal information

9. The Driver Software is being installed.



10. If USB Driver is installed successfully, [KDT PLC USB Loader CICON] appears.

Click [Close] to finish installation.



11. If USB Driver is installed successfully, [KDT PLC USB Loader CICON] appears under [Universal Serial Bus Controllers]



12. CICON can connect PLC through USB cable.

